



PLEASE READ AND SAVE THESE INSTRUCTIONS

FRESHEN AIRE SCENTED AIR MOVER
W/ NEGATIVE ION GENERATOR

OWNER'S MANUAL

P-150N, P-250NT, P-260NT, P-450NT
(115V/60Hz)



XPOWER MANUFACTURE, INC.
688 S 6th Avenue
City of Industry, CA 91746
Tel: 626-285-3301 Fax: 626-285-3302
www.xpower.com



INDEX

Introduction	2
Operation	3
Safety Instructions	4
Specifications	5
Parts List	6
Maintenance/Troubleshooting	7
Products & Accessories	8
Warranty/Service	9
Warranty Registration Form	10

INTRODUCTION

Use XPOWER Scented Air Movers with Anion switch to enhance ambiance and indoor air quality. A patented scent cartridge quickly fragrances the air and is easily refilled with a scented bead fragrance of your choice. The unit's built in ionizer generates revitalizing negative ions to reduce pollutants such as airborne dust, allergens, and malodors. Enjoy a boosted energy/mood as ionized air helps to increase oxygen flow and decrease fatigue. Available in models from 1/8 HP to 1HP, these professional level multifunctional utility air movers are precision built for efficient ventilating and drying.

Industry Leading Design

- Super Quiet Motor
- Lightweight
- Easy Carrying Handle
- Rugged Housing
- 3-Hour Timer (except P-150N)
- 3 or 4 Speed Switch

Multiple Applications /Uses

- Jan/San
- Hotels/Hospitality
- Spas & Salons
- Retail
- Gyms & Fitness Centers
- Home

What's inside: Air Mover, Refillable Scented Bead Cartridge, Lime Scented Bead Sample

			
0°	20° (kickstand)	45°	90°

AIR MOVER STORAGE:

Air Movers can be stacked (up to 4) on their sides for storage.

NOTICE: Stacking feature is not secure for transportation.



OPERATION

READ ALL INSTRUCTIONS BEFORE OPERATING

1. Prior to plugging the unit into the power source, inspect completely for any shipping damage.
2. Plug the electrical cord into the power outlet.
3. Carefully place the unit on a stable, flat, dry surface.
4. Position unit to desired angle to direct air flow.
5. Turn switch to desired speed.
6. To generate negative ions, flip green anion switch from OFF (O) position to ON (I).
7. Make sure unit operates normally and air flow vents are not obstructed.
8. To reduce the risk of injury, close supervision is necessary when an appliance is used near children. Do not allow children to play with or around an Air Mover at any time.

SETTING OPTIONAL TIMER

Turn dial to select desired time (1-180 minutes)

"ON" position sets unit for continuous use

** No Timer feature for P-150N

SPEEDS



FILLING SCENTED CARTRIDGE

1. Remove scent cartridge from the air mover by turning counter-clockwise while unit is positioned facing you.
2. Flip hinged top open.
3. Open scented bead packet sample that is included with your purchase.
4. Fill cartridge according to the scent intensity desired.
5. Reassemble by screwing cartridge back into the unit clock-wise.



WARNING: KEEP OUT OF REACH OF CHILDREN

SAFETY INSTRUCTIONS



WARNING - TO REDUCE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:


1. To prevent electric shock, do not operate the unit in standing water. Never plug in or unplug the unit with wet hands or while standing in water.
2. To avoid risk of injury, do not direct air flow at face or body.
3. To reduce the risk of fire or electric shock, do not use the Air Mover with any solid-state speed control device.
4. Use only with GFCI protected receptacles. Please contact a qualified electrician for verification and / or installation of a GFCI receptacle if necessary.
5. Do not operate the Air Mover with a damaged cord or plug. Discard the unit or return it to an authorized service facility for examination and/or repair.
6. Unplug the Air Mover from the power supply before servicing or cleaning.
7. Do not run the power cord under carpeting. Do not cover the power cord with throw rugs, runners, or similar coverings. Place the power cord away from traffic area to prevent tripping.
8. Do not allow children to play with or around the Air Mover at any time.
9. Do not move or carry the Air Mover while unit is operating.
10. It's Automatically Operated Device, To Reduce The Risk Of Injury Disconnect From Power Supply Before Servicing.

SPECIFICATIONS

Model	P-150N	P-250NT	P-260NT	P-450NT			
Volt / Frequency	115V / 60Hz						
Power	1/8 HP	1/5 HP		1/3 HP			
Amp	1.5 Amps	2.3 Amps		3.8 Amps			
Rated Airflow (On High)	700 CFM	800 CFM		2000 CFM			
RPM	650/950/1200	1000/1250/1500	450/650/1100/1500	1000/1350/1600			
Speeds	Three		Four	Three			
Unit / Box Weight (LBS)	9.1 / 10.8	9.9 / 11.1	10.0 / 11.2	16.3 / 20.3			
Unit / Box Size (L "x W" x H")	10.7x12.4x13.3 / 13.6x12.8x11			13.9x14.8x14.6 / 15.5x15x15.2			
Power Cord (Length/Size)	10'/18 AWG			20'/18AWG			
3-Hour Timer	No						
Negative Ion Switch	Yes						
Positions	4 (0°, 20° Kickstand, 45°, 90°)						
Overheating Protection	Thermally Protected						
Housing	Injection Mold / Polypropylene (PP)						
Safety Certificates	ETL / C-ETL						

PART LIST

Item No.	Parts Name	Item No.	Parts Name
1	Negative Ion Switch	2	Capacitor
3	Negative Ion Generator	4	Grid Cover (Motor Side)
5	Left Housing	6	Switch & Timer plate
7-1 / 7-2	Switch / Timer (except P-150N)	8-1 / 8-2	Switch / Timer Knob (except P-150N)
9	Motor	10	Power Cord
11	Fan	12	Right Housing
13	Grid Cover(Fan Side)	14	Fragrance Cartridge
15	Air Outlet Grid Cover	16	Kick Stand
17	Rubber Feet (Not Shown)	18	Screws and Nuts (Not Shown)



MAINTENANCE/TROUBLESHOOTING

1. To keep unit clean, use a damp cloth to wipe the surface of the housing.
2. Never clean Air Mover by rinsing or spraying directly with water.
3. When not in use, unplug and store unit in a dry indoor place out of reach of children.
4. Always disconnect Air Mover from its power source before performing any maintenance or cleaning.

For any problems not listed below, call your local distributor or contact the XPOWER Service Department.

PROBLEM	POSSIBLE CAUSE	SOLUTION
Air Mover not running	No power input	Plug in the Air Mover & check
	Switch not turned on	Turn on switch
	Air Mover fan wheel jammed	Remove material jamming fan wheel
	Intake or exhaust blocked	Turn unit off and allow to cool, then remove blockage
Air Mover vibrates	Accumulation of dirt on fan blades	Clean Air Mover fan Blades

PRODUCTS & ACCESSORIES

Visit www.xpower.com for Complete Product Selection

- Air Movers
- Axial Fans
- Air Scrubbers
- Dehumidifiers
- Pet Force Dryers
- Pet Stand Dryers
- Cage Dryers
- Inflatable Blowers

Additional Scented Bead Fragrances Available at
Amazon.com and Airchaser.com (XPOWER master distributor)

XPOWER MANUFACTURER, INC. 688 S 6th Ave City of Industry, CA, USA
Tel: 626-285-3301 Fax: 626-285-3302

XPOWER LIMITED WARRANTY (USA)

XPOWER's Limited Warranty covers the unit (excludes POWER CORD) from defects in material and craftsmanship. The Warranty covers normal use for a term of one year from the original date of purchase including parts, labor and one way shipping. Non-contiguous states must pay for roundtrip freight. A purchase receipt must be provided.

Important!

This warranty does not cover or apply to defects due directly or indirectly to misuse, abuse, disassembly, alteration, corrosive chemicals, improper voltage, fire, flood, negligence, accident, improperly or incorrectly performed maintenance or repair, or failure to perform necessary maintenance or repair, or if the use of this product is not in compliance with the instructions and specifications for its use.


Service

For Warranty service and parts replacement (US users only), you must:

- A. Call 1-855-855-8868 for a RMA (Return-Merchandise-Authorization) number.
- B. Have original proof of purchase.
- C. Use the original undamaged packaging or an industrial certified packaging method.

End user will be responsible to ship the unit (with RMA Number showing on the shipping label) to the XPOWER Service Department. XPOWER to inspect, assess and advise the repairs needed and the applicable cost, if any. For users outside the US, please contact XPOWER Distributor in your country or region for Warranty service and parts replacement.

From: _____



TO:

XPOWER MANUFACTURE, INC.
688 S 6th Avenue
City of Industry, CA 91746



For your product warranty, please complete and mail / fax this form to XPOWER MANUFACTURE, INC.
Address: 240 Clary Ave., San Gabriel, CA 91776. Tel: 626-285-3301 Fax: 626-285-3302
(For your convenience, register your product online at xpower.com)

Company Name / Contact Person / Title _____

Address _____ City _____

State / Province _____ Zip _____ Country _____

Phone _____ Fax _____ E-mail _____

Model # _____ Serial #: _____

Date of Purchase ____ / ____ / ____ Purchased From _____

Additional Comments / Suggestions _____